



Lifespan of Tractel[®] Height Safety Equipment

Textile PPE equipment – Mechanical PPE equipment –
Self-retracting fall arresters – Lifelines

Lifespan of Tractel® Height Safety Equipment

Tractel® no longer indicates lifespan on fall arrest equipment

In fact, Tractel® Personal Protective Equipment (PPE) can be used without restrictions from their manufacturing date provided that :

- Use is in accordance with the instruction manual.
- The instruction manual procedures for storage and transport are met.
- A periodic inspection is carried out at least every year by a competent person who, after inspection, will authorise in writing that the PPE is fit to be returned to service.
- A full written history is available for the product that you intend to use.

Products covered* :

- Tractel® **textile PPE equipment** such as harnesses, lanyards, ropes and energy absorbers
- Tractel® **mechanical PPE equipment** such as stopcable, stopfor™
- blocfor™ **self-retracting fall arresters**
- Tractel® **lifelines**



* Refer to the original manual.

Reduction of life due to environmental conditions

The life of the product may be reduced by ingrained dirt , paints & solvents, UV degradation...

It is the responsibility of the competent person carrying out the inspection and the user carrying out pre-use checks to ensure the product is safe for use.

Fall

If the product has been used to stop a fall, it must be removed from use.

